

Interproof

FOR CREATIVES AND MARKETING

Instructions for Interproof RubOns



1. To transfer the RubOns you need only a burnishing tool, a pencil and a pair of scissors.



2. The object's surface must be dry and free of oil and dust. It must have a non-repellent surface. RubOns should only be transferred at room temperature.



3. First cut out the image you want to transfer, allowing an adequate border around it. You should cut as close to the image as possible only for objects with a highly convex shape.



4. Remove the protective backing from the reverse side and position the RubOn. Avoid applying any pressure to the image in order to prevent prematurely transferring individual elements of the image.



5. Hold the RubOn securely in place and rub all parts of the image with a burnishing tool or pencil. Objects with soft surfaces (e.g. photos, Chromolux) should be tested beforehand to see how to prevent rub marks.



6. Grey areas indicate that the image has already separated from the carrier material. Hold the carrier material tightly in position on one end while you lift it from the other end. In case part of the image is still on the carrier material, flip it back into position and repeat rubbing.



7. Now remove the protective backing and place it with the siliconized side onto the transferred image. Using the burnishing tool or pencil, once again rub everything very carefully.



8. In some instances it is technically necessary for us to apply adhesive to the entire printing surface. If this is the case, light traces of adhesive could be visible after the transfer.

Drip a small amount of lighter fluid onto a tissue.



9. Try to wipe in the direction along the fine lines. It is usually sufficient to wipe once from one side to the other.



10. If you still don't feel confident transferring your RubOns yourself, request extra samples with your order to test the process. With a bit of practice it will go much easier, and along the way you can test your object's surface without having to use your own prints.

And if you prefer, we are happy to transfer the RubOns for you.

You may not believe it, but thanks to Interproof, RubOns have been available in Germany for 30 years. They are still the perfect solution for printing individual pieces.